20

I Init ' mm

# **SKEK-SET** Stripped Hex Head Screws/Bolts Removal Socket Sets

🞾 Easy operation



• Material/Finish					
		SKEK-SET			
Socket Body		SCM435 Manganese Phosphate Film			
Socket Holder	Rail	Carbon Steel Nickel Chrome Plating			
	Holder	Carbon Steel Nickel Plating			

#### Application

For removing hex head bolts and hex nuts with damaged corners

- A set of sockets that can remove hex head bolts and hex nuts with damaged corners that cannot be removed by ordinary tools.
- The spiral edges inside the socket firmly bite into and remove hex head bolts and hex nuts with damaged corners.

Edge Edge biting mark



- Can also be used for screws with round heads as long as the edge bites into it.
- Dedicated for right thread removal.
- A set of sockets for each insertion angle. Insertion angle 6.35 **SKEK-6.35-4SET** Insertion angle 9.5 **SKEK-9.5-8SET**
- The socket is stored in the socket holder for compact portability. The socket will not fall out even if turned upside down or shaken.
- Using the holes in the socket holder rail, it can be mounted on a wall or in a toolbox.

 Skipped Hex Head Scrw-Bolts Removal Sockets
 Mass \*2

 Insertion Angle
 Nominal of Applicable Hexagonal Width Across Flats
 (g)

 SkEK-6.35-4SET
 6.35
 5.5 77.8 10
 81

 SkEK-9.5-8SET
 9.5
 8 10 12 13 14 16 17 19
 417

\*1: The socket and socket holder are a set.

SKEK-6.35-4SET Outer Dimensions W: 21 mm / Total length: 150 mm / H: 30 mm SKEK-9.5-8SET Outer Dimensions W: 26 mm / Total length: 200 mm / H: 42 mm

\*2: Total mass of socket/socket holder.

### • Usage example

For cases where corners are damaged due to turning tools with shallow contact.

For cases where corners are crushed due to rust or corrosion from long-term exposure to outdoor environments.

For cases where corners are damaged due to attempts to forcibly remove tightly stuck screws. For cases where corners are damaged due to usage of incorrect sizes of tools.

## A Precautions for Use

- Cannot be used for left threads.
- The edges may not bite in depending on the material and hardness of the screws and nuts.
- The hexagonal part of the removed screws and nuts will have edge marks. These screws and nuts cannot be reused.
- Do not use with power tools like impact wrenches.
- Do not use in locations exposed to live wires, as it is made of metal.
- When the edges bite in, they will produce burrs in the hexagonal part of the screws. Be careful not to cut your hands on the burrs.
- The edges inside the socket are sharp. Be careful not to get injured by touching it.
- Do not use for any applications other than for removing screws.

### Set Contents

SKEK-6.35 SKEK-9.5 Stripped hex head screws/bolts removal sockets



### • SKEK-6.35-4SET Insertion Angle 6.35

	U						Unit . mm	
Part Number	Nominal of Applicable Hexagonal Width Across Flats	Lb Insertion Angle	t	D	D1	L	Mass (g)	
SKEK-5.5-6.35	5.5	6.35	5	8.8	13	23	14	
SKEK-7-6.35	7	6.35	6	10.9	13	23	14	
SKEK-8-6.35	8	6.35	8	11.5	13	23	14	
SKEK-10-6.35	10	6.35	10	14.8	13	23	17	
• SKEK-9.5-4SET Insertion Angle 9.5								
Part Number	Nominal of Applicable Hexagonal Width Across Flats	Lb Insertion Angle	t	D	D1	L	Mass (g)	
SKEK-8-9.5	8	9.5	8	11.5	19	32	40	
SKEK-10-9.5	10	9.5	10	14.8	19	32	41	
SKEK-12-9.5	12	9.5	12	17	19	32	44	
SKEK-13-9.5	13	9.5	12	18.5	19	32	46	
SKEK-14-9.5	14	9.5	14	19.7	19	32	48	
SKEK-16-9.5	16	9.5	14	22.2	22	32	66	
SKEK-17-9.5	17	9.5	16	23.5	22	35	80	
SKEK-19-9.5	19	9.5	16	26	22	35	92	

## Usage

) Mount  $\fbox{\textbf{SKEK}}$  to a commercially available socket wrench, etc.

②Push **SKEK** vertically against the hex head bolt or hex nut until the edges bite in.

<sup>③</sup>While pressing the head of the socket wrench from above, turn it in the loosening direction and remove the hex head bolt or hex nut. The spiral edges securely bite in<sup>\*1</sup>, allowing the screw to be turned and removed.



\*1: When the edge does not bite in and slipping occurs, remove <u>SKEK</u> using a socket wrench, and tap it lightly with a plastic hammer until it bites into a hex head bolt, hex nut, etc. Hitting with a hammer will transmit the impact to the part where the screw is attached. Be sure to pay attention to the place of use.



• Part number specification

SKEK-9.5-8SET 41